



KIT COMPONENTS

Tandem Axle Spring Hanger Kit

Spring hangers for the tandem kit are welded on the bottom of the frame. The spacing of the hangers is generally 4.25" LONGER than the distance between the spring eyes. This takes into consideration the length of the center equalizer used. All measurements taken from center of brackets and center of spring "eyes". Tandem axle double eye springs require spring shackles at the equalizer mount to allow spring movement.

K71-G03-06 (86521) contains the following components:

#	Qty.	TDE Part #	DX Part #	Description
1	2	17130	013-122-02	Tandem Equalizer
2	8	44536	018-011-05	Spring Shackle Links (short)
3	14	10830	007-612-00	Shackle Bolt
4	14	10688	006-727-00	Nylon Lock Nut
5	6	17144	028-049-00	Spring Hanger

