

Date: January 2, 2013

**Subject: Introduction of Torflex® Axle Lift Kits**

In keeping with our continual commitment to product innovation, Dexter Axle is pleased to announce the introduction of our #10 Torflex® lift kit. No need to buy a new axle with an increased down start angle or remove the axle and add a spacer to the frame.

If your trailer has #10 Torflex® axles that are side mounted and you would like to raise the unit, we now offer the means to do this by simply bolting a lift kit to the existing axle side mount hanger. This will increase your frame height by 2.63". The part number of the #10 lift kit is K71-707-02 and includes enough parts to do a tandem axle unit. **Note:** Lift kit cannot be used with 3" tall brackets.

**Kit Includes:**

Part Number	Quantity	Description
003-377-02	4	#10 frame spacer brackets 2.63" tall
005-111-00	24	Plain 5/8" washers
006-126-00	16	Hex lock nuts 5/8"-18
007-177-00	16	Hex cap bolts 5/8"-18 x 1.50" long
059-886-00	1	Instruction sheet



Look for the 2013 release of the Torflex® lift kits for #9, #11, and #12 axles.

Please contact your Dexter sales engineer if you have additional questions or need further assistance.



Rick Kapsa  
Product Manager